


FIG. 1






FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8






FIG. 9




FIG. 10




FIG. 11

0000 0000b : No program for decode in the disk  
0000 0001b : Packed PCM audio  
0000 0010b : AC-3 audio  
0000 0011b : MPEG audio  
0000 0100b : AAC audio  
0000 0101b : MPEG layer-3 audio  
0000 0110b : ATRAC3 audio  
0000 0111b : WMA audio  
0000 1000b : DTS audio  
0000 1001b : Twin-VQ audio  
0000 1010b : Q Design audio  
others : reserved for other coding mode

FIG. 12

0000 0000b : This disk has no program for decoding.  
0000 0001b : This disk has the program for decoding.  
others : reserved

FIG. 13